



Part # 03-103

## Fender Flares (Will Fit E-Z-GO TXT 2014+)



### ITEMS INCLUDED

- Fender Flares (4)
- Push Rivets (20)



### TOOLS NEEDED

- 9/32" Drill Bit
- Drill
- Marker

We recommend professional installation. If you choose not to have this product installed by a professional, we highly recommend that you exercise caution, care, and patience when installing this product, as it involves drilling holes into your car's body.

*\*Specific cart model may not be shown*

## STEP 1

Test fit fender flare to bodywork to determine best placement. Holding the fender flare in place, mark locations to be drilled.



## STEP 2

Drill first hole using a 9/32" drill bit. Ensure area behind body work is clear to avoid potential damage to wiring or other bodywork.



## STEP 3

Insert barbed push rivet half-way to secure fender flare. Check other marked holes to ensure proper placement before drilling. Once sure of placement, rotate fender flare out of the way and drill other holes.



## STEP 4

Push the first rivet in to secure fender flare and then insert other rivets.

Repeat Steps 1-4 for other three fender flares.



# INSTALLATION COMPLETE

E-Z-GO®, TXT®, RXV® and S4® are registered trademarks of Textron Innovations, Inc. Club Car®, Precedent®, DS®, Onward® and Tempo® are registered trademarks of Ingersoll Rand, Inc. Yamaha®, Yamaha® Drive®, Drive2®, G-14®, G-16®, G-19®, G-22® and G-29® are registered trademarks of Yamaha Golf-Car Company. Any reference to Club Car®, E-Z-GO®, or Yamaha® or their associated trademarks, word marks, and products are only for purposes of identifying golf carts with which this MadJax product is compatible. MadJax products are aftermarket parts and are not original equipment parts. MadJax is not connected to, affiliated with, sponsored by, or endorsed by either Textron Innovations, Inc., Ingersoll Rand, Inc., Yamaha Golf Cart Company, or any of their parent or subsidiary companies.

