

JAKES LIFT KITS
EZ-GO 1989-1994 MARATHON GAS
PART # 6200

PARTS LIST




ITEM	QTY.
A. COIL SPRING RISER	2
B. SHOCK EXTENSIONS	2
C. FRONT AXLE	1
D. STEERING RISER	1
E. 1 ½" X 3/8", 2" X 3/8" BOLTS WITH LOCK NUTS (FOR FRONT)	1
F. WARNING LABEL	1
G. 2 ½ X 3/8 NUTS & BOLTS FOR SHOCK EXTENSIONS (PICTURED IN ITEM B)	2

JAKES LIFT KITS
EZ-GO 1989-1994 MARATHON GAS

INSTALLATION INSTRUCTIONS

FRONT INSTALLATION

1. Jack up the front end of the cart and place it on jack stands. You will be installing larger wheels and tires so raise the cart high enough to accommodate for the additional height.
2. Remove the tie rod joints from the spindles.
3. Remove the spindles from the front axle. Clean and lubricate these bolts for the reinstallation of the spindles.
4. Remove the front axle. Clean and lubricate these bolts for the new axle.
5. Using the bolts from the old axle install JAKES front axle (Item C).
6. Reinstall the spindles to JAKES axle.
7. Install JAKES steering riser (Item D) to the spindle on the passenger side of the cart. (NOTE: On some models you may need to grind both sides of the spindle for this to fit.) The 1 ½ bolt (Item E) goes through the existing hole in the spindle. The 2" bolt (Item E) goes through the remaining hole in the extension. (NOTE: The 2" bolt must be installed with the head toward the tire.)
8. Attach the steering rod end to JAKES steering extension.
9. Reattach the tie rods to the spindles.
10. Securely tighten all bolts.
11. Install JAKES recommended wheel and tire size 22 x 11 x 10 wheels and tires with a 3x5" offset for maximum performance. **NOTE:** Your stock wheels and tires will work but is **not** recommended!
12. Take the cart off of the jack stands and lower the cart.
13. Drive the cart forward 10-20 feet and check the toe-in. (Proper toe-in should be approximately 1/8" in.)



REAR INSTALLATION

1. Jack up the rear end of the cart and place jack stands on the frame in front of the springs. You will be installing larger wheels and tires so raise the cart high enough to accommodate the additional height.
2. Remove the wheels and tires.
3. Remove the bottom shock bolts. Keep these bolts for mounting the shock extensions (Item B.)
4. Lower the axle and remove the springs.
5. Place JAKES coils spring risers (Item A) on top of the axle spring mounts which have rubber pads on top.
6. Replace the springs.
7. Bolt JAKES rear shock extensions (Item B) using the stock shock bolts to the original bottom shock mounts.
8. Bolt the shocks to the rear shock extensions with the supplied nuts and bolts (Item G.)
9. Double check all nuts and bolts for tightness.
10. Install JAKES recommended wheel and tire size 22 x 11 x 10 wheels and tires with a 3 x 5" offset for maximum performance. **NOTE:** Your stock wheels and tires will work but is **not** recommended!
11. Included is a warning label (Item F) which is to be placed on the steering column or another visible area and is to be read by all operators.